

LOADED GEAR™

VX-500 Adjustment Instructions



1 Unzip the side of the VX-500 and put the vest on. Locate the internal cummerbund and adjust it to the desired tightness using the Velcro surfaces.



2 Zip up the side of the VX-500 and fasten the buttoned strap to prevent any unintentional movement of the zipper.



3 Unbutton the large front section, open it up, and then adjust the internal cummerbund by placing the large Velcro sections at the desired tightness position.



4 Close the large front section and then button the securing strap to the inside of the VX-500's front section.



5 To further adjust the tightness of the waist section, locate the adjustment straps on the right side of the vest in the rear pocket and then pull them to adjust the tightness of the vest.



6 To adjust the shoulder sections of the vest, open up the shoulder pads and pull on the Velcro strap inside to adjust the tightness. Once finished, close the shoulder pads to secure the straps in place.