

Sight scope in @ 100yds! Once sighted in...

To zero scope in: Loosen the Hex screw on top of turret cap and twist the turret cap to 100-yds.