

CAUTION: DO NOT LOOK DIRECTLY AT THE SUN VIEWING THE SUN OR ANY LIGHT SOURCE WITH THIS OPTICAL DEVICE CAN CAUSE PERMANENT EYE DAMAGE.

INSTRUCTIONS FOR USE

1. Remove protective lens covers
2. Hold monocular with one hand and use the other hand to focus in on an object

FOCUSING

Bring viewed objects into focus by slowly twisting the Main Focus Wheel knob in the center of the barrel, until you have a clear image. For a sharper image use the Fine Focus Wheel; image clarity will increase

TWIST UP EYECUP

Non-Eyeglass: Raise eyecup by twisting to eliminate extraneous light

Eyeglass Wearers: Lowering the eyecup will bring your eyes closer to the monocular lens, thus providing an improved field of view.

TRIPOD ADAPTABLE FITTING

The monocular is equipped with a built in standard tripod adaptor located on the body of the monocular near the focus wheel, where the neck strap can be attached. The tripod adaptor can be attached to most tripods for easy hands-free use.

HOW TO CARE FOR YOUR MONOCULAR

1. When wiping the eyepiece or objective lens, use the included lens cloth or a soft lint-free cloth. To remove any visible dust or debris by blowing or using a lens brush.
2. To remove any remaining dirt or smudges, add 1 or 2 drops of alcohol to a lens cloth and gently wipe lens and eyepiece in a circular motion.
3. Always use lens caps when monocular are not in use
4. Store monocular in a moisture-free area.

IMPORTANT: Never attempt to clean your monocular internally or attempt to take monocular apart.

Parts of the Monocular

