



10x30mm Binocular Manual

Read all instructions before use



Parts Of The Binocular


- A. Right Eye Diopter
- B. Eyepiece
- C. Center Focus
- D. Objective Lens
- E. Tripod Adaptable Fitting

DO NOT use this optical product to view the Sun or any light source. CAUTION: Viewing the Sun can cause permanent eye damage.

This binocular is a precision instrument designed to provide many years of pleasurable viewing. This booklet will help you achieve optimum performance by explaining how you can adjust the binocular to your eyes, and how to care for this instrument. Read the instructions carefully before using your binoculars.

Eye Adjustments

Fig.1 INTERPUPILLARY DISTANCE ADJUSTMENT



HOW TO ADJUST FOR DISTANCE BETWEEN YOUR EYES

The distance between the eyes, called "interpupillary distance" (IPD), varies from person to person. To achieve perfect alignment of lens to eye, follow these simple steps.

1. Hold your binocular in the normal viewing position.
2. Grasp each barrel firmly. Move the barrels closer together or further apart until you see a single circular field. Always re-set your binocular to this position before using.

HOW TO ADJUST FOR INDIVIDUAL EYE STRENGTH

Human eyes are as individual as fingerprints. This binocular has a feature which allows you to adjust the binocular to your vision. Follow the focusing instructions for your binocular style.

Focusing

CENTER FOCUS-has a central focusing wheel between the barrels.

1. Adjust interpupillary distance (Figure 1)
2. Keep both eyes "open" at all times.
3. Using a lens cover or your hand, cover the objective (front) lens of the side with the "diopter setting"
4. Using the center focus wheel, focus the distant object being viewed.
5. Cover the other objective lens, then view the same object as explained above.

6. Using the "diopter setting" adjustment ring, focus the same object being viewed. Caution should be used as over turning or forcing the diopter eyepiece can damage or cause the eyepiece to break away from the chassis.

7. Your binocular should be adjusted for your eyes. Focus at both far and near distance can now be attained simply by turning the center focus wheel.

Waterproof / Fog-Proof

Your binocular may be designed and built utilizing the latest waterproof and fog-proof technology. This binocular is O-ring sealed for complete protection. Fog proof protection is achieved from dry nitrogen purging to remove all internal moisture.

Instructions For Care

If handled with care, this binocular will provide years of trouble-free service. Like any fine optical instrument your binocular should be given sensible care. Non waterproof models should not be exposed to excessive moisture.

1. Keep the lens covers (that come with your binocular, except compact models) on the lenses when binoculars are not in use.
2. Avoid banging and dropping.
3. Store in a cool, dry place.
4. Looking directly at the sun with your binocular may be very harmful to you eyes.



LIMITED LIFETIME WARRANTY

BINOCULARS

BARSKA® Optics, as manufacturer, warrants this new precision optical product to be free of original defects in materials and/or workmanship for the length of time specified by this warranty. This warranty does not include damage caused by abuse, improper handling, installation, maintenance, normal wear-and-tear, unauthorized repairs or modifications and tampering in anyway.

This warranty is limited to the original purchaser and is not transferable. This warranty applies only to products purchased in the United States of America.

In the event of a defect within 30 days, the consumer must return the defective unit to the BARSKA dealer (the place of purchase) at his/her own expense.

Beyond 30 days, BARSKA products should be sent to the following address for warranty repairs. Products must be packed carefully and sturdily to prevent damage in transit, and returned freight prepaid to:

BARSKA OPTICS
Repair Department
855 Towne Center Drive
Pomona, CA 91767

For additional and updated information
please visit our website at www.barska.com

Please email info@barska.com or call 1.888.666.6769 for Return Merchandise Number (RMA#) before any returns. NOTE: All merchandise received without a valid RMA # will be returned to shipper at his/her own expense.

Please include all of the following when returning BARSKA products for service and/or replacement:

1. Please write your complete details (Name, Address, Telephone #, E-mail address, RMA#, etc.)
2. Purchase receipt or Proof of Purchase. (Original/Copy)
3. A brief explanation of the defect.
4. A Check/Money Order of \$20.00 to cover inspection, shipping and handling. *Please allow 6-8 weeks for delivery.

This product will either be replaced or repaired at the discretion of the warrantor. If it's a discontinued item, we will replace the product with an equivalent product. Should the repair not be covered by this warranty, an estimate will be sent for your approval. Non-warranty repairs or refurbishing of your optical products are always provided at a reasonable cost.

BARSKA® Optics shall not be liable for any consequential, incidental and/or contingent damages whatsoever. We will not pay shipping, insurance or transportation charges from you to us, or any import fees, duties and or taxes. This warranty supersedes all previous BARSKA® Optics warranties.

1. Blow away any dust or debris on the lens (or use a soft lens brush)
2. To remove dirt or fingerprints, clean with a soft cotton cloth rubbing in a circular motion. Use of a coarse cloth or unnecessary rubbing may scratch the lens surface and eventually cause permanent damage.
3. For a more thorough cleaning, photographic lens tissue and photographic-type lens cleaning fluid or isopropyl alcohol may be used. Always apply the fluid to the cleaning cloth-never directly on the lens.

VERY IMPORTANT

Never attempt to clean your binocular internally or try to take it apart.