



Spotter And Tripod Manual

CAUTION: DO NOT LOOK DIRECTLY AT THE SUN VIEWING THE SUN OR ANY LIGHT SOURCE WITH THIS OPTICAL DEVICE CAN CAUSE PERMANENT EYE DAMAGE.



Parts of the Spotting Scope

- A - Eyepiece
- B - Zoom Ring
- C - Focus Knob
- D - Objective Lens
- E - Mounting Plate



Parts of the Tripod

- a - Tripod Adaptor Screw
 - b - Mounting Platform
 - c - Mounting Screw
 - d - Pan and Tilt Control Handle
 - e - Legs
 - f - Feet
- actual model may vary

Tripod Set Up

Spread the tripod legs and set the tripod on a firm support.

Mounting

1. Position the mounting plate onto the mounting platform of the spotting scope then tighten mounting screw located under the mounting plate to firmly lock spotting scope body onto the mounting plate.
2. Make sure screws are locked/tight and the tripod is on a stable surface.

Viewing

1. With spotting scope mounted securely in place, point the objective lens at the object. Take the cover off objective lens and remove the lens cap off the eyepiece.
2. Rotate the zoom ring of the eyepiece to the lowest magnification.
3. Look into the eyepiece, then turn the focus knob to focus object clearly.
4. Use the Pan and Tilt Control Handle to slowly move, pan, and tilt to desired position.

Spotting Scope Care

- Store your spotting scope with the protective lens caps in a cool and moisture free environment.
- To clean the lenses, use a soft bristle brush to remove any dust or dirt and then use a soft cloth moisture with alcohol. Wipe lenses from center outward and avoid touching the lens, as fingerprints will smear the lens.
- To clean body parts, use a soft cloth with warm water and mild soap to remove dirt.
- Do not dismantle the spotting scope or the eyepiece. If they need repair or adjustment, please contact BARSKA customer service.

Tripod Care

- When not in use, compress tripod legs.
- Store your tripod in a cool dry area.

3 YEAR LIMITED WARRANTY

SPOTTING SCOPES

BARSKA warrants this new precision optical product to be free of defects in material and/ or workmanship under normal use for a period of 3 years from the date product is purchased. This limited warranty is delimited to repair or replacement only. This warranty does not include damage caused by improper use or maintenance. BARSKA disclaims all liabilities for incidental or consequential damages such as misuse, abuse, accident (such as dropping), flood, service or repairs other than those performed by BARSKA, acts of nature, or arising out of any breach of this warranty. Altering the product under any circumstances will automatically void the warranty.

This warranty DOES NOT COVER ANY ACCESSORIES. Loss of the product or lens caps/covers, eyepieces, cases/pouches, or straps are not covered. Product normal wear and tear are not covered and the determination of such is at the sole discretion of BARSKA.

For service under this limited warranty, please have available the proof of purchase and the purchase date and location as well as a detailed description of the problem. This warranty is not transferable and only applies to the original purchaser with a proof of purchase from BARSKA or from an authorized dealer. This warranty applies only to products purchased within the United States, excludes the Hawaiian Islands and all U.S. territories in the Caribbean and the Pacific.

BARSKA will examine and go through troubleshooting procedures, product repair or replacement of defective part(s) or units with new part(s) or provide a new unit if necessary during the warranty period. Shipping/handling charges may apply and are at Baraka's sole discretion. Purchaser shall be required to prepay Shipping/handling charges with a check or money order to BARSKA at time product is returned. The Return Merchandise Authorization Number (RMA#) and shipping/handling charge MUST be obtained from BARSKA in advance of return. BARSKA shall not be liable for damages or loss occurring during shipping. Please visit via www.barska.com or call 1.888.666.6769 for more information.

BARSKA reserves the right to modify or discontinue, without prior notice to the purchaser, any model or style of the product. BARSKA will determine, at its sole discretion, whether a product will be repaired or replaced. BARSKA reserves the right to discontinue or change any feature of its products at any time. If an exact replacement or product is not available, BARSKA reserves the right to provide a part or product that matches as closely as possible.

LIMITATION OF REMEDIES

BARSKA disclaims any warranties, express or implied, whether of merchantability of fitness for a particular use, except as expressly set forth herein. The sole obligation of BARSKA under this limited warranty shall be to repair or replace the covered product, in accordance with the terms set forth herein. BARSKA expressly disclaims any lost profits, general, special, indirect or consequential damages which may result from breach of any warranty, or arising out of the use or inability to use any BARSKA product. Any warranties which are implied and which cannot be disclaimed shall be limited in duration to a term of three year from the date of original retail purchase. Some states do not allow the exclusion or limitation of incidental or consequential damages or limitation on how long an implied warranty lasts, so the above limitations and exclusions may not apply to you.

BARSKA 855 Towne Center Drive, Pomona, CA 91767

Note: All information, feature, and specification displayed herein are based on the data available at the time of publishing, thus they are subject to change without notice. All product pictures displayed herein are for illustration purposes only. The actual product may vary due to different circumstances