



Reusable Dehumidifier

Description

The perfect combatant against excess moisture, preventing it from causing bad odors and other moisture related problems in small areas. As the water retaining pouch fills with moisture the patented humidity indicator will slowly change from blue to pink. When the humidity indicator has completely changed from blue to pink it is ready to be dried out. This way you can ensure that even places with no ventilation at all are kept fresh – odor and moisture free. Perfect for early morning fogged windows, mildew, musty odors and other moisture related problems. The unit should weigh less than 7 ounces when it is ready to be dried out. You can repeat this process as needed.

Read these instructions before getting started. This will ensure optimal performance and safe use of your product.

WARNING

- Remove the plastic bag before first use.
- Do not try to open or cut the cloth.
- Do not leave the product in reach of children or pets. Although the contents are not toxic, swallowing the contents may cause dehydration or choking.
- Avoid rubbing or scratching the humidity indicator as this may damage the top layer. The humidity indicator is extra sensitive particularly after microwave regeneration.

MICROWAVE DRYING WARNINGS

- During the microwave drying process this product will become very hot and hot water vapor will be released. Handle with extreme caution.
- Do not exceed recommended microwave drying time and wattage.
- Only microwave dry this product when the moisture retaining bag is completely full and the humidity indicator is completely pink.
- Microwaving an empty reusable dehumidifier may cause overheating and damage the product and microwave plate.
- Do not leave unattended during microwave drying.
- Keep microwave area clean. Oil or grease might damage the reusable dehumidifier or cause scorching to the fabric. Dispose of the product if it appears greasy or stained.
- The reusable dehumidifier can only be recharged in a microwave oven.

Microwave Instructions

When the humidity indicator changes from blue to pink it is ready to be dried out.

Attention!! Read the MICROWAVE DRYING WARNINGS section before recharging the reusable dehumidifier.

1. Place the pouch on a microwave safe plate in the center of the microwave with the humidity indicator facing up.
2. Heat your reusable dehumidifier for four (4) minutes on High ($\pm 600W$).

CAUTION During the microwave drying process your reusable dehumidifier will get extremely hot. The water in your reusable dehumidifier will heat up and evaporate. The humidity indicator will turn from pink to blue and your reusable dehumidifier will be ready to use again.

Specifications

- This product has been manufactured according to the highest quality standards and does not contain AZO Dyes, Cobalt (II) Dichloride or Dimethyl fumarate.
- Active drying agent: SiO₂

Disposal

- At the end of its service life the product can be disposed in the trash (household waste).
- Always comply with local regulation regarding recycling and the collection of waste and inquire with your local government if needed.

1 YEAR LIMITED WARRANTY

DEHUMIDIFIER

BARSKA® Optics, as manufacturer, warrants this product to be free of original defects in materials and/or workmanship for the length of time specified by this warranty. This warranty does not include damage caused by abuse, improper handling, installation, maintenance, normal wear-and-tear, unauthorized repairs or modifications and tampering in anyway.

This warranty is limited to the original purchaser and is not transferable. This warranty applies only to products purchased in the United States of America and Canada.

In the event of a defect within 30 days, the consumer must return the defective unit to the BARSKA dealer (the place of purchase) at his/her own expense.

Beyond 30 days, BARSKA products should be sent to the following address for warranty repairs. Products must be packed carefully and sturdily to prevent damage in transit, and returned freight prepaid to:

BARSKA® OPTICS
Repair Department
855 Towne Center Drive
Pomona, CA 91767

For additional and updated information
please visit our website at www.barska.com

Please email info@barska.com or call 1-888-666-6769 for Return Merchandise Number (RMA#) before any returns.

NOTE: All merchandise received without a valid RMA # will be returned to shipper at his/her own expense.

Please include all of the following when returning BARSKA products for service and/or replacement:

1. Please write your complete details (Name, Address, Telephone #, E-mail address, RMA#, etc.)
 2. Purchase receipt or Proof of Purchase. (Original/Copy)
 3. A brief explanation of the defect.
 4. A Check/Money Order of \$10.00 to cover inspection, shipping and handling.
- *Please allow 6-8 weeks for delivery.

This product will either be replaced or repaired at the discretion of the warrantor. If it's a discontinued item, we will replace the product with an equivalent product. Should the repair not be covered by this warranty, an estimate will be sent for your approval. Non-warranty repairs or refurbishing of your optical products are always provided at a reasonable cost.

BARSKA® Optics shall not be liable for any consequential, incidental and/or contingent damages whatsoever. We will not pay shipping, insurance or transportation charges from you to us, or any import fees, duties and or taxes. This warranty supersedes all previous BARSKA® Optics warranties.