


## Safe Handle Position



Confirm that the safe handle is in the vertical position to successfully open the safe.



NOTE: If the safe handle is angled, the safe will not unlock successfully. Realign the safe handle to the vertical position to successfully open the safe.