Selfie Stick

W WINBEST® by ♦ BARSKA®

Notes Before Use

- Read the instructions before use.
- Based on HID wireless communication technology, compatible with operating systems iOS4.0 and Android 4.0 or later.
- Turn off any other nearby bluetooth devices to avoid the signal interference.
- Do not dismantle the product.
- Do not use corrosive solvent to clean product.
- Do not charge product in high temperature environments or under strong light.
- Do not get product wet or use in damp weather conditions.
- Do not throw product into fire.
- Please do not drop.

Bluetooth Pairing

- Press and hold the Bluetooth shutter button 3 seconds, to turn product on, Blue LED light will flash guickly.
- 2. Turn on mobile device's Bluetooth.
- 3. Search for the Bluetooth device named " XD-10 Selfie Stick ".
- Click "XD-10 Selfie Stick" to pair the Bluetooth devices. No password is needed, the LED light will flash slowly, indicating a successful pairing.

Note: Product automatically goes to stand by mode within 2 minutes of activation.


Capture Images

- 1. After a successful pairing.
- 2. Carefully mount mobile device into the cradle.
- Activate the camera on the mobile device.
- 4. Extend selfie stick to desired length.
- 5. Press Bluetooth shutter button to capture image.
 6. Press and hold Bluetooth shutter button for 3
- seconds, to turn product off, LED light will turn off.

Internal Battery Indicator Light

When the internal battery indicator light is red this indicates that the battery is low. Place smaller end of the USB cord into the charging port and the other end to a USB power source. When fully charged the internal battery indicator light will be blue.





Working Environment Temperature	-10°C - +40°C
Working Environment Relative Humidity	10% - 90%
Charging Voltage	DC 5.0v
Charging Time	1 hour
Standby Time	100 hours