INSTRUCTIONS FOR USE



Model AA10614 15X-45X50 SPYSCOPE



INSTRUCTIONS FOR ASSEMBLY

- 1. Insert supplied screw through hole in Base.
 Attach Base to Pedestal.
- 2. Attach assembled Base and Pedestal to telescope by screwing onto telescope mount.

OPERATING INSTRUCTIONS

- 1. Adjust telescope to desired angle using Angle Adjustment Knob.
- 2. Rotate Zoom Adjustment to desired zoom magnification (15x to 45x).
- 3. Adjust focus using Focus Adjustment
- 4. Look through Eyepiece. Adjust zoom magnification and focus as necessary.