



LEVEL ED User Manual





Parts Of The Spotting Scope

A. Eyepiece

B. Zoom Ring

C. Focus Knob

D. Fine Focus Knob

E. Objective Lens

F. Mounting Plate

G. Eyepiece Unlock Button

Eyepiece

- 1. Remove the dust cover on the spotting scope by pressing down on the eyepiece unlock button then turning the dust cover counter clock wise.
- 2. Remove the dust cover on the eyepiece, line up the red line on the eveniece with the red dot on the spotting scope.
- 3. Screw the eyepiece clockwise into spotting scope.

Observation

- 1. Remove objective lens cap and point spotting scope in desired location of the objective to be viewed.
- 2. Rotate the zoom ring of the eyepiece to the lowest magnification.
- 3. Look into the eyepiece, then turn the focus knob til image is clear, after turn the fine focus to further focus the image.
- 4. Rotate the zoom ring to be desired magnification and adjust the object with focus knob if necessary.

Care and Maintenance

- Store your spotting scope with the protective lens caps in a cool and moisture free environment.
- To clean the lenses, use a soft bristle brush to remove any dust or dirt and then use a soft cloth moisture with alcohol. Wipe lenses from center outward and avoid touching the lens, as fingerprints will smear the lens.
- To clean body parts, use a soft cloth with warm water and mild soap to remove dirt.
- Do not dismantle the spotting scope or the eyepiece. If they need repair or adjustment, please contact the BARSKA dealer in your country. For further details please refer to the warranty.



LIMITED LIFETIME WARRANTY

SPOTTING SCOPE

BARSKA® Optics, as manufacturer, warrants this new precision optical product to be free of original defects in materials and/or workmanship for the length of time specified by this warranty.

This warranty does not include damage caused by abuse, improper handling, installation, maintenance, normal wear-and-tear, unauthorized repairs or modifications and tampering in anyway.

This warranty is limited to the original purchaser and is not transferable. This warranty applies only to products purchased in the United States of America.

In the event of a defect within 30 days, the consumer must return the defective unit to the BARSKA dealer (the place of purchase) at his/her own

Beyond 30 days, BARSKA products should be sent to the following address for warranty repairs. Products must be packed carefully and sturdily to prevent damage in transit, and returned freight prepaid to:

> **BARSKA OPTICS** Repair Department 855 Towne Center Drive Pomona, CA 91767

For additional and updated information please visit our website at www.barska.com

Please email service@barska.com or call 1.888.666.6769 for Return Merchandise Number (RMA#) before any returns. NOTE: All merchandise received without a valid RMA # will be returned to shipper at his/her own expense.

Please include all of the following when returning BARSKA products for service and/or replacement:

- 1. Please write your complete details (Name, Address, Telephone #, E-mail address, RMA#, etc.)
- 2. Purchase receipt or Proof of Purchase. (Original/Copy)
- 3. A brief explanation of the defect. *Please allow 6-8 weeks for delivery.

This product will either be replaced or repaired at the discretion of the warrantor. If it's a discontinued item, we will replace the product with an equivalent product. Should the repair not be covered by this warranty, an estimate will be sent for your approval. Non-warranty repairs or refurbishing of your optical products are always provided at a reasonable cost.

BARSKA® Optics shall not be liable for any consequential, incidental and/or contingent damages whatsoever. We will not pay shipping, insurance or transportation charges from you to us, or any import fees, duties and or taxes. This warranty supersedes all previous BARSKA® Optics warranties.