




Professional Tripod

Parts of the Tripod

Head Parts

- A. 1/4-20 Screw
- B. Plate Release Button
- C. Quick Release Plate
- D. Bubble Level
- E. 3/8 Screw
- F. Quick Release Plate Lever
- G. Panning Handle Adjustment Lever



Body Parts

- H. Altitude Tensioner and Lock
- I. Azimuth Tensioner and Lock
- J. Grip
- K. Upper Leg Locks
- L. Lower Leg Locks
- M. Center Column Height Knob
- N. Pan Handle
- O. Column Crank
- P. Center Column

How To Use The Professional Tripod

- To adjust height of legs release upper and lower leg locks (K and L). Extend legs to desired height and lock upper and lower leg locks.
- To change angle of leg spread push down variable angle leg spread and gently pull leg out for desired angle. Release button. Repeat this step with other legs. NOTE: When pushing legs back to original position. It is normal to hear clicks from the variable angle leg button.
- To adjust center column height, loosen center column height knob (M), slowly raise column by holding the tripod head to desired position and tighten in place.
- Make sure locks/knobs are locked/tight (M, I, K, and L), and the tripod is on a stable surface.
- To release mounting platform (C) pull down the quick release knob (B) and slide out of place. Under mounting platform will be a knob. Remove the mounting screw size (A or E) you don't need and store it. Attach mounting platform to the bottom of device and tighten into place. Carefully slide entire assembly back into place on head. Tighten knob on the opposite side of the leveling bubble (not pictured).

NOTES

- Mounting maximum weight is 6.75 lbs.
- Post interchangeable. Remind: keep other post while removing them

- With mounted item securely in place, point the objective lens to the object, look through the eyepiece and slowly move pan and tilt control handle (N) to desired position. Tighten the panning handle adjustment lever (G) to secure your viewing angle.

How To Take Care Of The Professional Tripod

- When not in use, lower tripod legs to minimum height with upper and lower locks (K and L), lower center column to minimum height (P) and secure in place.
- Place tripod in carrying case (included) and store your tripod in a cool dry area



1 YEAR LIMITED WARRANTY

TRIPODS & ADAPTORS

BARSKA® Optics, as manufacturer, warrants this new precision optical product to be free of original defects in materials and/or workmanship for the length of time specified by this warranty. This warranty does not include damage caused by abuse, improper handling, installation, maintenance, normal wear-and-tear, unauthorized repairs or modifications and tampering in anyway.

This warranty is limited to the original purchaser and is not transferable. This warranty applies only to products purchased in the United States of America and Canada.

In the event of a defect within 30 days, the consumer must return the defective unit to the BARSKA® dealer (the place of purchase) at his/her own expense.

Beyond 30 days, BARSKA® products should be sent to the following address for warranty repairs. Products must be packed carefully and sturdily to prevent damage in transit, and returned freight prepaid to:

BARSKA
Repair Department
855 Towne Center Drive
Pomona, CA 91767

For additional and updated information please visit our website at www.barska.com

Please email info@barska.com or call 1.888.666.6769 for Return Merchandise Number (RMA#) before any returns.

NOTE: All merchandise received without a valid RMA # will be returned to shipper at his/her own expense.

Please include all of the following when returning BARSKA® products for service and/or replacement:

- Please write your complete details (Name, Address, Telephone #, E-mail address, RMA#, etc.)
- Purchase receipt or Proof of Purchase. (Original/Copy)
- A brief explanation of the defect.
- A Check/Money Order of \$25.00 to cover inspection, shipping and handling.

*Please allow 6-8 weeks for delivery.

This product will either be replaced or repaired at the discretion of the warrantor. If it's a discontinued item, we will replace the product with an equivalent product. Should the repair not be covered by this warranty, an estimate will be sent for your approval. Non-warranty repairs or refurbishing of your optical products are always provided at a reasonable cost.

BARSKA® shall not be liable for any consequential, incidental and/or contingent damages whatsoever. We will not pay shipping, insurance or transportation charges from you to us, or any import fees, duties and or taxes. This warranty supersedes all previous BARSKA® warranties.