





User Manual For Depository Safe

Large Keypad Depository Safe




Parts of the Control Panel
A. Handle
B. Logo Plate and Key Access
C. Indicator Lights
D. Key Pad

Standard & Compact Keypad Depository Safe



Parts of the Control Panel
A. Lock Knob
B. Key Cover and Key Access
C. Indicator Lights
D. Key Pad



Parts of the Inside of the Safe Door
E. Initialization Button
F. Battery Compartment

* Actual models may vary

WARNING: Avoid leaving door open and unattended; it will allow unauthorized individuals to reprogram the safe, gaining full access to the safe and contents.

OPENING THE SAFE WITH ACCESS KEY

For Large Keypad Depository Safe

1. To expose the key access, remove logo plate screws with provided Allen wrench
2. Insert access key into key access, and turn clockwise to open

For Standard & Compact Keypad Depository Safe

1. To expose the key access, gently lift off the key cover
2. Insert access key into key access, and turn clockwise to open

NOTE: Store keys in a secure place. NOT inside of the safe

BATTERIES

1. Remove battery cover on the inside of the safe door
2. Insert 4 new AA batteries into the battery compartment and pay attention to the polarity of the batteries
3. Replace compartment cover

CREATING PERSONAL PIN CODES

Safe retains only two 3-8 digit pin codes

1st Personal Pin Code

1. With safe open, press and release the initialization button located on the inside of the safe door. Yellow indicator light will be on.
2. On the key pad input your 3-8 digit pin code and press and release either "A" or "B" to confirm. Yellow indicator light will turn off.

2nd Personal Pin Code

1. On the key pad press and release "0" twice. Press and release the initialization button located on the inside of the safe door. Yellow indicator light will be on.
2. On the key pad input your 3-8 digit pin code and press and release either "A" or "B" to confirm. Yellow indicator light will turn off.

TESTING PERSONAL PIN CODES

1. With safe door open, and the handle/lock knob in the lock position. Enter in 1st personal pin code on the key pad and press and release either "A" or "B" to confirm.

Successful Save

- You will hear 2 short beeps
- The green indicator light will flash
- Move handle to the right to retract bolts

Unsuccessful Save

- You will hear 9 short beeps
- Handle will not move and bolts will stay extended
- Repeat steps CREATING PERSONAL PIN CODES

2. To test 2nd personal pin code, enter in 2nd personal pin code on the key pad and press and release either "A" or "B" to confirm. See "Successful Save" and "Unsuccessful Save" above
3. Test a pin code that is not registered to make sure the safe does not open to complete testing process

OPENING & CLOSING SAFE WITH PERSONAL PIN CODES

OPEN:

1. On the key pad enter in either of your 3-8 digit pin codes and press and release either "A" or "B" to confirm.
2. Turn the handle/lock knob to the unlock position and pull the safe door open

NOTE

After entering pin, you have 5 seconds to turn the knob before the mechanism re-locks automatically

CLOSE:

To close safe, close door and turn knob to the lock position

LOCK OUT

Lock out mode is activated when the wrong personal pin code is entered

- 3 consecutive times, Lock out mode will last 20 seconds
- 6 consecutive times, Lock out mode will last 5 minutes

CHANGING PERSONAL PIN CODES

Follow steps in "CREATING PERSONAL PIN CODES"



User Manual For Depository Safe

LOW BATTERY WARNING

After entering correct personal code and the green and red indicator lights are flashing this indicates that the batteries are low. Follow steps in "BATTERIES"

NOTE

Safe may still be opened in low battery state depending on battery voltage. If safe cannot be opened please use emergency key. All registered pin codes remain stored

CARE AND MAINTENANCE

- If necessary use a damp cloth to clean the safe. DO NOT use chemicals or cleaning agents
- Keep liquids away from the control panel. Spills on the control panel will cause damage and possibly electric shock
- Secure safe in a proper area to prevent it from falling and causing damage or injury
- DO NOT over stuff the contents of the safe, it can damage the motor mechanism or the contents
- DO NOT disassemble the product. For all repairs and maintenance, contact BARSKA Customer Service
- DO NOT place emergency keys inside of safe



1 YEAR LIMITED WARRANTY

SAFES

BARSKA warrants this new safe to be free of original defects in material and/or workmanship under normal use for a period of twelve (12) months from the date product is received by purchaser. This warranty does not include damage caused by improper installation or maintenance. Damage from misuse, abuse, accident (such as dropping), normal wear and tear, excessive fire, flood, or acts of nature. Damage from service or repairs other than those performed by BARSKA. Labor, cost and shipping charges for the removal and replacement of defective parts beyond the initial twelve-month warranty period. All transportation and shipping charges. Removing or altering the seal under any circumstances will automatically void the warranty.

This warranty is limited to original purchaser and is not transferable. This warranty applies only to products purchased in the United States.

Please email info@barska.com or call 1.888.666.6769 for Return Merchandise Number (RMA#) before any returns. The RMA number must appear on the outside of the shipping package. Product must be packed carefully and sturdily in its original packaging to prevent damage in transit and returned freight pre-paid to:

BARSKA OPTICS
Repair Department
855 Towne Center Drive
Pomona, CA 91767

Please include all of the following when returning BARSKA products for service and/or replacement:

1. Please write your complete details (Name, Address, Telephone #, E-mail address, RMA#, etc.)
2. Purchase receipt or Proof of Purchase. (Original/Copy)
3. A brief explanation of the defect
4. A Check/Money Order of cover inspection, shipping and handling. Charges are as follows:

Large Keypad Depository Safe = \$60.00
Standard Keypad Depository Safe = \$40.00
Compact Keypad Depository Safe = \$40.00

*Please allow 6-8 weeks for delivery.

BARSKA will examine and test returned product and repair or replace defective part(s) or units with new part(s) or a new unit if necessary within the warranty period. Purchaser is required to remit above charges to BARSKA for return shipping and handling at time product is returned. If repair is required after warranty period expiration, purchaser will be charged for replacement parts and return shipping.

BARSKA® Optics shall not be liable for any consequential, incidental and/or contingent damages whatsoever. We will not pay shipping, insurance or transportation charges from you to us, or any import fees, duties and or taxes. This warranty supersedes all previous BARSKA® Optics warranties.