



User Manual Keypad Portable Safe

Read all instructions before using this safe.

WARNING

- For security purposes, change the factory default code as soon as possible. Factory default code is 1234.

- Avoid leaving door open and unattended; it will allow unauthorized individuals to reprogram the safe, gaining full access to the safe and contents.

- Store emergency keys in a secure place; NOT inside of the safe.


- Keep area in front of safe door clear; safe door is spring loaded and will pop open forward, be careful when opening safe.

- Keep safe away from children.

NOTE: BARSKA is not responsible for any damages due to moisture.

NOTE: BARSKA is not responsible if the safe or its contents gets lost or stolen.

PARTS OF THE SAFE



- A. Key Access
- B. Indicator Lights
- C. Key Pad

- D. Initialization Button
- E. Battery Compartment
- F. Removable Shelf

OPENING THE SAFE WITH ACCESS KEY

1. Insert access key in key access, and turn counter-clockwise to open.

NOTE: Be careful when opening the safe; keep area in front of safe door clear.


2. Remove access key.

NOTE: Store keys in a secure place. NOT inside of the safe.

BATTERIES

1. Remove battery cover located on the inside of the safe under the key pad. (E)

2. Insert 4 new Alkaline AA batteries into the battery compartment and pay attention to the polarity of the batteries.



3. Replace battery cover.

NOTE: Do not mix old and new batteries.

CREATING PERSONAL PIN CODE

Safe retains one 3-8 digit pin code.

1. With safe open, press and hold the initialization button (D) located on the inside of the safe under the keypad for 3 seconds. The green indicator light will flash twice.
2. On the keypad input your 3 – 8 digit pin code (press the initialization button when finished if pin code is not 8 digits). The yellow indicator light will flash twice and 2 beeps will be heard. Re-enter your pin code (press the initialization button when finished if pin code is not 8 digits).

Successful

Green Flash will be seen along with 2 beeps.

Unsuccessful

Red flash will be seen along with several beeps. Lock out mode is activated when the wrong personal pin code is entered 3 consecutive times. The alarm will be triggered and will last 1 minute. Lock out mode will last 2 minutes. During this period, pressing any button is invalid.

TESTING PERSONAL PIN CODE

1. Enter in personal pin code on key pad. Door will automatically unlock and open.

NOTE: Be careful when opening the safe; keep area in front of safe door clear.

2. Test a pin code that is not registered to make sure the safe does not open to complete testing process.

OPENING & CLOSING SAFE WITH PERSONAL PIN CODE

OPEN:

To open safe, on the key pad enter in personal pin code. Door will automatically unlock and open.

NOTE: Be careful when opening the safe; keep area in front of safe door clear.

CLOSE:

To close safe, close door and the door will automatically lock in place.

LOCK OUT

Lock out mode is activated when the wrong personal pin code is entered 3 consecutive times. The alarm will be triggered and will last 1 minute. Lock out mode will last 2 minutes. During this period, pressing any button is invalid.

CHANGING PERSONAL PIN CODE

Follow steps in "CREATING PERSONAL PIN CODE".

SOUND

Press and hold the #1 button until all the indicator lights flash to turn the sound either on or off.

See reverse side for more information

VIBRATION ALARM

The safe will alarm for 1 minute when the safe is rattled.

VIBRATION ALARM ON

To turn on the alarm system: Press and hold "#4" key for 3 seconds, you will see the red Indicator Light flash 5 times, indicating that the alarm system is on.

You can activate the alarm no matter the safe door is open or close.

VIBRATION ALARM OFF

Turn off the alarm system: open the safe with the correct pin code.

Note: The vibration alarm will turn off when you open the safe with the correct pin code. Please activate the alarm system each time as needed.

LOW BATTERY WARNING

When batteries are low; yellow indicator light will flash following the green indicator light when operating the safe. Please change batteries as soon as possible. Follow steps in "BATTERIES".

NOTE: Safe may still be opened in low battery state depending on battery voltage. If safe cannot be opened, please use Access key. Registered pin code remains stored.


MOUNTING

The safe may be mounted to the floor. The pre-drilled mounting holes are located under the safe.

DO NOT mount safe without anchoring to the wall behind the safe!

When mounting to a wall check the wall or cabinet for structural soundness.

1. Check location for concealed items such as wires, pipes etc.



2. Get the appropriate anchors for the type of floor or wall you will be mounting the lock box to (wood, tile, concrete etc).

3. Mark the surface to drill holes for the anchors you will be using.

4. Drill the appropriate size hole for the anchors you will be using.

5. Once mounted, test the strength to make sure the safe is securely mounted.

CARE AND MAINTENANCE

- If necessary use a damp cloth to clean the safe. DO NOT use chemicals or cleaning agents.

- Keep liquids away from the control panel. Spills on the control panel will cause damage and possibly electric shock.

- Secure safe in a proper area to prevent it from falling and causing damage or injury.

- DO NOT over stuff the contents of the safe, it can damage the motor mechanism or the contents.

- DO NOT disassemble the product. For all repairs and maintenance, contact BARSKA Customer Service.

- DO NOT place emergency keys inside of safe.



1 YEAR LIMITED WARRANTY

SAFE

BARSKA warrants this new item to be free of original defects in material and/or workmanship under normal use for a period of twelve (12) months from the date product is received by purchaser. This warranty does not include damage caused by improper installation or maintenance. Damage from misuse, abuse, accident (such as dropping), normal wear and tear, excessive fire, flood, or acts of nature. Damage from service or repairs other than those performed by BARSKA. Labor, cost and shipping charges for the removal and replacement of defective parts beyond the initial twelve-month warranty period. All transportation and shipping charges. Removing or altering the seal under any circumstances will automatically void the warranty.

This warranty is limited to original purchaser and is not transferable. This warranty applies only to products purchased in the United States.

Please e-mail info@barska.com or call 1.888.666.6769 for Return Merchandise Number (RMA#) before any returns. The RMA number must appear on the outside of the shipping package. Product must be packed carefully and sturdily in its original packaging to prevent damage in transit and returned freight pre-paid to:

BARSKA OPTICS
Repair Department
855 Towne Center Drive
Pomona, CA 91767

Please include all of the following when returning BARSKA products for service and/or replacement:

1. Please write your complete details (Name, Address, Telephone #, E-mail address, RMA#, etc.)
2. Purchase receipt or Proof of Purchase. (Original/Copy)
3. A brief explanation of the defect
4. A Check/Money Order of \$20.00 to cover inspection, shipping and handling.

*Please allow 6-8 weeks for delivery.

BARSKA will examine and test returned product and repair or replace defective part(s) or units with new part(s) or a new unit if necessary within the warranty period. Purchaser is required to remit above charges to BARSKA for return shipping and handling at time product is returned. If repair is required after warranty period expiration, purchaser will be charged for replacement parts and return shipping.

BARSKA® Optics shall not be liable for any consequential, incidental and/or contingent damages whatsoever. We will not pay shipping, insurance or transportation charges from you to us, or any import fees, duties and or taxes. This warranty supersedes all previous BARSKA® Optics warranties.