


# Reusable Dehumidifier



## Description

The perfect combatant against excess moisture, preventing it from causing bad odors and other moisture related problems in small areas. As the water retaining pouch fills with moisture the patented humidity indicator will slowly change from blue to pink. When the humidity indicator has completely changed from blue to pink it is ready to be dried out. This way you can ensure that even places with no ventilation at all are kept fresh – odor and moisture free. Perfect for early morning fogged windows, mildew, musty odors and other moisture related problems. The unit should weigh less than 7 ounces when it is ready to be dried out. You can repeat this process as needed.

Read these instructions before getting started. This will ensure optimal performance and safe use of your product.

## WARNING


- Remove the plastic bag before first use.
- Do not try to open or cut the cloth.
- Do not leave the product in reach of children or pets. Although the contents are not toxic, swallowing the contents may cause dehydration or choking.
- Avoid rubbing or scratching the humidity indicator as this may damage the top layer. The humidity indicator is extra sensitive particularly after microwave regeneration.

## MICROWAVE DRYING WARNINGS

- During the microwave drying process this product will become very hot and hot water vapor will be released. Handle with extreme caution.
- Do not exceed recommended microwave drying time and wattage.
- Only microwave dry this product when the moisture retaining bag is completely full and the humidity indicator is completely pink.

- Microwaving an empty reusable dehumidifier may cause overheating and damage the product and microwave plate.
- Do not leave unattended during microwave drying.
- Keep microwave area clean. Oil or grease might damage the reusable dehumidifier or cause scorching to the fabric. Dispose of the product if it appears greasy or stained.
- The reusable dehumidifier can only be recharged in a microwave oven.

## Microwave Instructions



When the humidity indicator changes from blue to pink it is ready to be dried out.

Attention!! Read the MICROWAVE DRYING WARNINGS section before recharging the reusable dehumidifier.

1. Place the pouch on a microwave safe plate in the center of the microwave with the humidity indicator facing up.
2. Heat your reusable dehumidifier for four (4) minutes on High (±600W).

**CAUTION** During the microwave drying process your reusable dehumidifier will get extremely hot. The water in your reusable dehumidifier will heat up and evaporate. The humidity indicator will turn from pink to blue and your reusable dehumidifier will be ready to use again.

## Specifications

- This product has been manufactured according to the highest quality standards and does not contain AZO Dyes, Cobalt (II) Dichloride or Dimethyl fumarate.
- Active drying agent: SiO<sub>2</sub>

## Disposal

- At the end of its service life the product can be disposed in the trash (household waste).
- Always comply with local regulation regarding recycling and the collection of waste and inquire with your local government if needed.