



# BARSKA®

## GLX Green 5mW Tactical Laser Sight with Picatinny Rail and 1" Ring



### DESCRIPTION

BARSKA's 5mW Green Laser Sight GLX features external riflescope style windage and elevation (W/E) adjustments for quick, high precision targeting. Zeroing in your laser is a quick and easy process. The tactical design integrates a tactical edged bezel into the strong T6 aluminum body for added protection. The diamond cut exterior grip improves the mounting capability of the picatinny 1" mounting ring included with the laser sight.



**WARNING:** BE CERTAIN THAT YOUR FIREARM IS NOT LOADED AND POINTED AWAY FROM YOU IN A SAFE DIRECTION

**ATTENTION:** THIS BARSKA LASER SIGHT IS A POWERFUL TARGETING DEVICE THAT REQUIRES SPECIAL ATTENTION WHEN OPERATING. CAREFULLY READ THE FOLLOWING INSTRUCTIONS AND SAFETY PRECAUTIONS BEFORE USING THIS PRODUCT.

**CAUTION:** UNAUTHORIZED USE MODIFICATIONS OF ADJUSTMENTS OR PERFORMANCE OF PROCEDURE OTHER THAN SPECIFIED HEREIN MAY RESULT IN DANGEROUS/HAZARDOUS RADIATION EXPOSURE.

**LASER LIGHT:** AVOID DIRECT EYE EXPOSURE.

WARNING KEEP OUT OF REACH OF CHILDREN.

DO NOT POINT LASER AT PEOPLE, PETS, AIRPLANES, SHINY/HIGHLY REFLECTIVE SURFACES, OR ANY OTHER OBJECT NOT INTENDED FOR DESIGNATED USE.

### MOUNTING

Your laser sight is equipped with a Picatinny Rail. This rail will attach your laser to your firearm.

1. Slide the laser sight into the bore of the Picatinny rail.
2. Once the sight is in the rail tighten it in place by using an Allen wrench.
3. Slide the rail onto your firearm, then tighten it in place.

### BATTERY

This device is powered by one 3v (CR123A) Lithium Battery.

1. Unscrew the cable switch by turning it counter clockwise
2. Insert the battery so that the positive pole of the battery faces out.
3. Replace the switch back on the laser sight. Turn clockwise to tighten the cable switch onto the sight. Make sure that you have screwed the switch on tightly.



### WINDAGE & ELEVATION

Adjustments must be made in the shooter's position of the sight. This laser sight has been factory calibrated. Should you require adjusting the windage and elevation remove turret caps and see chart below to distinguish which of these knobs you need to turn and in which direction.

CC: Counter Clockwise  
C: Clockwise

	Up	Down	Left	Right
Elevation	C	CC		
Windage			CC	C



### ACCESSORIES INCLUDED

- Continuous push button on/off cap
- Momentary on/off long cable switch
- 1" picatinny rail ring with removable cross-bar
- 1" High Dovetail .22/Airgun Ring

### NOTE

- After 3 minutes of continuous use, turn laser off for 1 minute
- If operating laser in cold weather (under 68° F) let laser warm up by turning it on for 30 seconds before use. (Actual warm up time may vary depending on surrounding environment)
- Test laser periodically during periods of non-usage to ensure adequate battery level

### TECHNICAL DATA

Visible Laser Class IIIA Laser Product

Length 138mm  
 Weight 204g  
 Main Tube Diameter 1 inch  
 Output Power <5mW  
 Wavelength 532(±10)nm  
 Reach 1000 YDS  
 Operating Temperature 59°F-95°F  
 Adjustment Windage & Elevation  
 Material T6 Aluminum  
 Battery Type CR-123A Lithium

**WARNING:**

AVOID EXPOSURE LASER RADIATION IS EMITTED FROM THIS APERTURE

DANGER

LASER RADIATION AVOID DIRECT EYE EXPOSURE

---

<p>Max Output&lt;5mW            WAVELENGTH 532(±10)nm            Class IIIA Laser Product            FDA NO.:0720007</p>	<p>5mW Green Laser Sight w/ring            Model: AU11368            Made in China            Manufactured on 08/2013</p>
<p>This product complies with 21 CFR chapter 1, subchapter L.</p>	<p>BARSKA Optics            855 Towne Center Drive            Pomona, CA 91767</p>